


# Licence Keys OPC / Praesideo

ADC-5000-OPC | ADC-5000-VA | ADC-5000-OPC-VA



**BOSCH**

Installation Guide



1 	2 	3 	4 	$\Sigma$	 /OPC/OPC+VA $\leq 2048$
X	X	0064	OPC/VA/OPC+VA	0064	✓
X	X	0128	OPC/VA/OPC+VA	0128	✓
X	0128	0128	OPC/VA/OPC+VA	0256	✓
0128	0128	0128	OPC/VA/OPC+VA	0384	✓
X	X	0512	OPC/VA/OPC+VA	0512	✓
X	0128	0512	OPC/VA/OPC+VA	0640	✓
0128	0128	0512	OPC/VA/OPC+VA	0768	✓
0128	0128	0128	0512	0896	✓
X	0512	0512	OPC/VA/OPC+VA	1024	✓
0128	0128	1024	OPC/VA/OPC+VA	1280	✓
0512	0512	0512	OPC/VA/OPC+VA	1536	✓
0064	0128	0512	1024	1728	✓
0512	0512	1024	OPC/VA/OPC+VA	2048	✓
0128	1024	1024	VA	2176	✗
0064	0128	1024	1024	2240	✗
0512	1024	1024	VA	2560	✗
0128	0512	2048	VA	2688	✗
0064	0128	0512	2048	2752	✗
0512	0512	2048	VA	3072	✗
0128	1024	2048	VA	3200	✗
0064	0128	1024	2048	3264	✗
0512	1024	2048	VA	3584	✗
0128	0512	1024	2048	3712	✗
1024	1024	2048	VA	4096	✗

**Bosch Sicherheitssysteme GmbH**

Robert-Bosch-Ring 5

85630 Grasbrunn

Germany

**[www.boschsecurity.com](http://www.boschsecurity.com)**

© Bosch Sicherheitssysteme GmbH, 2013