



ALPHACOM E/XE USER GUIDE

IP & ANALOG MASTER STATIONS




IP Desktop Master Station



IP Flush Master Station



Analog Desktop/Wallmount Master Station



Dual Display Station (IP/Analog)



Contents

INTRODUCTION.....	6
MAKING INTERCOM CALLS	7
Starting and Ending a Handsfree Call	7
Using the Handset to Call	7
Setting to Private Mode	7
Calling to and From Noisy Environments.....	9
Adjusting the Sound / Volume Level	9
Muting the Microphone	9
If Someone is Not at Their Station	10
Waiting For a Busy Station to Become Free	10
Re-dialing	10
SEARCHING FOR A PERSON	11
Voice Paging - Calling a Group of Stations.....	11
Answering Voice Paging (Meet Me)	12
Search List - Options for Transferring Calls to Another Destination ...	12
Automatic Search	12
PRIORITIES	13
Priority Features	13
Priority Setting for the Station	13
ABSENCE MESSAGES	14
Leaving an Absence Message at Your Station	14
Leaving an Absence Message from a Remote Station	15
Deleting an Absence Message.....	15
VOICE / TEXT MESSAGES	16
Leaving a Call-back Message	16
Answering a Call-back Message.....	16
Leaving a Voice / Text Message at a Remote Station	16
Playing Back / Deleting Messages	17
Playing Back / Deleting Messages from a Remote Station	17
Voice Help.....	18
TRANSFER FEATURES	18
Inquiry Call.....	18
Call Transfer	18
Call Forwarding from Own Station.....	19
Follow Me - Forwarding from Remote Station	19
REMINDER / WAKE-UP CALL	20

RE-DIALING	20
CALL REQUEST	21
RADIO / MUSIC PROGRAMS	22
Selecting a Program	22
Turning Off or Toggling a Program	22
Scrolling Through Available Programs	22
Turning On/Off Programs to Other Stations	23
CONFERENCE	24
Simplex Conference (Push To Talk)	24
Duplex Conference (Handsfree)	24
DOOR OPENING	25
TELEPHONE CALLS	26
Making an Internal Telephone Call	26
Making an External Telephone Call	26
Calling From a Telephone To an Intercom Station	27
Receiving a Telephone Call at Your Station	27
POCKET PAGING	28
Paging With Answer Option	28
Paging Without Answer Option	29
Paging Without Calling an Intercom Station	29
Answering Paging (Meet Me)	30
DISPLAY INFORMATION	31
Information Display	31
Idle Station	31
Menu Selection	31
Conventional Name Search	32
Name Search in Subscriber Directory	33
Check Station Identity	33
PROGRAMMING DIRECT ACCESS KEYS - DAK	34
Programming DAK Directory Numbers and Functions	34
Deleting DAK Call Numbers and Functions	34
Direct Access Key Display Information	35
Editing DAK Text	35
LED INDICATIONS FOR IP FLUSH MASTER	36
Example of LED Indicator Use	36
USER QUICK REFERENCE	37

INTRODUCTION

AlphaCom E/XE is a powerful and flexible communication exchange/server designed to provide Critical Communication over IP (CCoIP) and serve a wide range of applications.

The information in this document pertains to all STENTOFON IP & Analog Master Stations with or without display, including IP and Analog Desk Master stations, IP & Analog Flush/Wallmount Master stations, Industrial Master stations and IP & Analog Dual Display stations.

Special functions that require additional equipment are indicated in the document where relevant.

☞ *Note that factory default settings for directory numbers and time-out periods are used in this manual. They may have been changed to meet the specific requirements of your AlphaCom exchange/server installation. If you are in doubt, please consult the STENTOFON supervisor at your site.*


Zenitel Norway AS and its subsidiaries assume no responsibilities for any errors that may appear in this publication, or for damages arising from the information in it. No information in this publication should be regarded as a warranty made by Zenitel Norway AS.

The information in this publication may be updated or changed without notice. Product names mentioned in this publication may be trademarks, they are used only for identification.

Zenitel Norway AS, Feb 2011

MAKING INTERCOM CALLS


Starting and Ending a Handsfree Call



To call another station:

- Dial the number of the station or, if the number has been pre-programmed:
- Press the direct access key (DAK)

The LED indicator lights up on both stations when the call is connected and you will hear a short tone.




To terminate the conversation:

- Press **C**

The LED indicator goes out.

Using the Handset to Call




To call another station:

1. Lift the handset
 - You will hear a dial tone.
2. Dial the number of the station.

To terminate the conversation:

- Replace the handset or press **C**

Setting to Private Mode





In Private mode, calls do not come through directly but are indicated by a ringing tone at both stations.

The privacy switch is different depending on whether it is an IP, Analog or Dual Display station.

To set the station to Private mode for IP Master stations:

- Press **C** and hold for 2 seconds.
 - **PRIVATE** will be displayed briefly and the **P** symbol will appear and start to flash.





To set the station to Private mode for Analog Master stations:

- Slide the privacy switch to the left across to **PRIVATE**.

To set the station to Private mode for the Dual Display station:

- Press the **P** button
 - A “muted loudspeaker”  icon will be displayed.

To answer a call while in Private mode:

- Press **M**
- or
- Lift the handset
 - for stations with handsets
- or
- Slide the privacy switch across to the right from **PRIVATE** to **OPEN**.
 - for Analog Master stations


within 30 seconds. After 30 seconds, the call attempt is automatically canceled.

☞ Your system may be set so that some calls are always in OPEN or PRIVATE mode regardless of switch setting. Incoming telephone calls are normally indicated by a private ringing tone.

To set the station back to open mode:

- Press **C** and hold for 2 seconds.
 - for IP Master stations (the **P** symbol will disappear)
- or
- Slide the privacy switch to the right across to **OPEN**.
 - for Analog Master stations
- or
- Press the **P** button
 - for the Dual Display station

Calling to and From Noisy Environments



If there is disturbing background noise:

- Press **M** and hold while you speak.
- Release **M** while you listen.

You are now in simplex mode.


The volume will increase at the listening end.

To go back to automatic direction switching:

- Tap **M** briefly.

Either party can use the M function.

Adjusting the Sound / Volume Level




For the IP Desk Master, the volume control is located on the LED indicator. For the IP/Analog Flush Master stations, the volume control is located on a separate button.

- Press the volume control button at either end to adjust the volume up or down to the level desired.

For the Analog Desk Master stations, the volume control is located on a slide switch.

- Slide the switch to the left or right to adjust the volume up or down to the level desired.



For the Dual Display station, the volume control is located on a control knob.

- Turn the volume control knob to adjust the volume up or down to the level desired.

Muting the Microphone



To mute the microphone:

- Press **0** and hold during the conversation.

To un-mute the microphone:

- Release **0**.


If Someone is Not at Their Station

Sometimes, the person you're calling may not be present at his/her station.

In this situation, you have several options:

- Page 11: ● Cancel and make a Group Call (or All Call)
- Page 12: ● Activate the pre-programmed search list
- Page 16: ● Leave a Call Back message
- Page 16: ● Leave a predefined voice/text message
- Page 20: ● Cancel and use the re-dial feature later
- Page 28: ● Activate the person's pocket pager

Waiting For a Busy Station to Become Free



If a station or a feature that you call is busy, you will hear a busy tone and your display will show Busy.


You can either:

- Press **C** to disconnect and try again later.
- or
- Wait for up to 30 seconds.

If the station or feature becomes free within 30 seconds, you will be connected automatically.

For information on the Busy Notify and Busy Override features, see the PRIORITIES section.

Re-dialing



You can program one of the single-touch DAKs on your station to re-dial the last intercom number dialed from the station.


For information on how to program DAKs, see the PROGRAMMING DIRECT ACCESS KEYS section.

The default directory number for the re-dial feature is **9532**.

For more information on re-dialing, see the RE-DIALING section.

SEARCHING FOR A PERSON

Voice Paging - Calling a Group of Stations



You can search for somebody by making a Group Call from any station if this function is not disabled in the exchange.

Each group has its own directory number. Default numbers are:

Group 1 - 5 : 84 - 88 (84 includes all subscribers)

Group 6 - 15 : 890 - 899

To make a Group Call:

1. Dial the directory number for the group.
2. Wait for the chime signal.
3. Press **M** while you are speaking.

The audio goes to all stations in the group.

If you want an answer:

- Wait

If not:

- Press **C**

The time-out period for answering is one minute by default.

To repeat your message:

- Press **M** while you are speaking.

To extend the waiting period by another minute:

- Tap **M** briefly

To make an All Call (all stations in the system):

- Dial **84**

For programming your group membership, consult the STENTOFON supervisor at your site.



Answering Voice Paging (Meet Me)




To answer voice paging:

- Dial **99** at the nearest intercom station within the answer period (1 minute).

You will be automatically connected to the person who initiated the call.

Search List - Options for Transferring Calls to Another Destination



Each station can have a pre-programmed search list for transferring calls to another destination when the subscriber is absent. The list can include an ordinary directory number, a Group Call number, or a message to a pocket pager.

To search for a person:

- Dial the subscriber number.

When no one answers the call:

- Press **9** to activate the first step on the search list.

If no one answers your search, you can activate the next step by pressing 9 once more.

If the station you call has no search list or if you have come to the end of the list, pressing **9** has no effect.

For programming your search list, consult the STENTOFON supervisor at your site.

Automatic Search

The system can be set up so that the search list is automatically activated when you get an absence message, busy tone or after a time-out for private calling.

PRIORITIES

Priority Features

Your station can be assigned one of several priority features. Please consult your STENTOFON supervisor for the assignment of these priority features to your station.

PRIVATE / Message Override

When the station you call is in Private mode:

- Dial **59** or press **M** to break through a private mode or an absence message (e.g. "Busy at the moment") left at the station.



Busy Notify (factory default)

When the station you call is busy:

- Dial **57** or press **M** to send an attention tone to the busy station. At the other end, the display shows the person who is calling.



Busy Override

When the station you call is busy:

- Dial **58** or tap **M** twice. This cancels the ongoing conversation and you will be connected.



Priority Setting for the Station

Your station is set up to have a priority level (one of four levels). Depending on the priority setting, outgoing calls will behave differently:

- Make outgoing calls in private
- Override private setting
- Override an absence message
- Connect you to a busy station (and disconnect the ongoing conversation)

ABSENCE MESSAGES

This feature requires additional equipment in the exchange for voice messages.

☞ *The message numbers are factory default settings and may have been changed in your installation.*

Leaving an Absence Message at Your Station

You can leave a prerecorded absence message at your intercom station. Whoever calls your station will hear the message. The messages also allow you to include appropriate information on the time, date and phone number.

You can choose from a list of prerecorded messages. See the list of messages and their numbers in the USER QUICK REFERENCE section.

To leave an absence message:

- Enter the message number
+ digits for time/date/phone no. (optional)
or M

If you enter the additional digits, you need not press M. The message is also accepted after a time-out.


For example, to leave the absence message “At lunch until 1 pm” at your station, do the following:

1. Enter **776**
 - You will then be prompted for the time which you enter in the 24-hour clock notation, e.g. 1300 for 1 pm.
2. Enter the time, e.g. 1300

The message will then be played back and displayed to you.

If you select the wrong absence message or enter the wrong time, date or number, press C to cancel the operation and you can begin again.

The LED light will flash and there will be an intermittent beep to indicate that there is an absence message.




Leaving an Absence Message from a Remote Station

If you are at another station and you want to leave an absence message on your own station:

- Dial your own station no. + 50 + message no. + digits for time/date/phone no. + M

Deleting an Absence Message



To delete an absence message:

- Dial **70**

You will hear: "No Messages".

And your display will show: No Messages

Your absence message is automatically deleted and the LED indicator will stop to flash.

To delete an absence message from a remote station:


- Dial **73** + own station number

VOICE / TEXT MESSAGES

This feature requires additional equipment for voice messages.

- ☞ *The message numbers are factory default settings and may have been changed in your installation.*

Leaving a Call-back Message




To leave a call-back message:

- Press **8** while connected to a station.

The voice message "Call me on number xxxx" is automatically registered at the other station, while the following text message will be displayed: Call me back

- ☞ *If there is no support for voice messages, only the text message will be displayed.*


Answering a Call-back Message



The LED indicator and display on your station will indicate that there is a message waiting. The number of messages is also shown.

- Dial **70** to play back the message.
- Press **8** to set up a conversation with the station that left the message.
- Press **9** to scroll through call-back messages without deleting them.

Leaving a Voice / Text Message at a Remote Station



Refer to the list of messages in the USER QUICK REFERENCE section.


- Dial the remote station number + 7 + message no. + additional digits for time/date/phone no. or M

For example, to leave the message "Call home" at remote station number 2525, dial:

2525 + 7 + 663 + M

The message "Call home" will then be registered at the remote station.

Playing Back / Deleting Messages



If you have received messages, the LED indicator on the station will flash and you will hear a beep at regular intervals.

To indicate that you are present and to play back any messages:

- Dial **70**

If there are any messages, they will be played back for you.

If there are several voice messages, you have the following options:

Press 0 : Delete the message and play back the next one (if any).

Press 1 : Repeat the message.


Press 7 : Play back the previous message.

Press 8 : Call sender of message (and delete the message).

Press 9 : Play back the next message without deleting the previous one.

Press C : Disconnect (and keep messages).

Playing Back / Deleting Messages from a Remote Station




To remotely play back the messages left at your station:

- Dial station number + 51

To remotely delete the messages left at your station:

- Dial station number + 51 + 0

Voice Help



This feature requires additional equipment.

The intercom station has a built-in system of voice help messages.


In some situations you will get a voice help message if you hesitate before carrying out the next step in a function. The help message stops when you press a key.

If you already know exactly what to do, there is no need to wait for a help message.

You will also get help information in the display.

TRANSFER FEATURES


Inquiry Call



When in conversation with a person:

1. Press **2** to park the ongoing conversation.
2. Dial the directory number of the other person or feature you want to reach.
3. By pressing **2** you can switch between the two conversations by keeping one parked (Broker function).
4. Press **C** to disconnect the ongoing conversation.

Call Transfer




When you have made an Inquiry Call, you can establish a conversation between the two other parties and disconnect yourself.

When in conversation with a person:

- Make an Inquiry Call to another station by pressing **2** + directory number.
- Press **3** to connect the two stations. Your own station is automatically disconnected.

REMINDER / WAKE-UP CALL



To set the reminder time that is within 24 hours:

- Dial **7883** + hour, minutes
(7883 + hhmm)

You will be prompted for the time which you enter in the 24-hour clock notation, e.g. 1500 for 3 pm.

For the above example, the display will show:

WaUp 15:00 28/03

To set the reminder time that is NOT within 24 hours:

- Dial **7883** + hour, minutes, day, month
(7883 + hhmm + DDMM)

Your station will ring at the time you have set.

To stop the ringing:

- Press any key on the station.

To delete the reminder time:

- Dial **7883** + **M**

There can only be one reminder/wake-up call per station.

RE-DIALING

To re-dial the last number:

- Dial **9532**

You can program the re-dial directory number (9532) into one of the Direct Access Keys (see the PROGRAMMING DIRECT ACCESS KEYS section).

☞ *It is not possible to re-dial telephone numbers.*

CALL REQUEST



Your call is registered, please wait.



To make a Call Request:

- Dial **623** + the station number

You will hear a voice message:

“Your call is registered. Please wait.”

The message is spoken in English, German and French.

The display will show: Call registered.

The LED indicator will flash and the station will beep until the call is answered.

To answer a Call Request at the called station:

- Dial **70**

The display shows the number and name for the first Call Request sender.

- Press **8** to call the sender and delete the Call Request from the list.

There is a notification tone for each Call Request and the LED indicator will start to flash.

The display shows the number of messages at your station waiting to be answered.

You also have the following options:

0	delete message without answering
1	repeat message
7	go to previous message
9	go to next message
C	disconnect without deleting messages

For handling call requests on stations with displays, the following codes, that are normally programmed in DAKs, are used:

- 7638 (Answer)
- 7637 (Up)
- 7639 (Down)
- 7630 (Delete)



Your call is registered, please wait.




The Call Request feature is usually used for dialing from a substation to a defined master station. The Call Request number is programmed on one of the buttons on the substation.

RADIO / MUSIC PROGRAMS

This feature requires additional audio sources. The radio channels, music or internal programs available will depend on your installation.

Selecting a Program



To select an audio program:

- Dial the Program Number

Program 1 - 6 dial 801- 806

Program 7 - 38 dial 8101 - 8132

Frequently used programs can be programmed to a DAK.

The program is, by default, temporarily interrupted by outgoing and incoming calls, but it remains on during Group Calls and All Calls.

Turning Off or Toggling a Program

To turn off an audio program:

- Press **C**

or

- Dial **800**

To toggle on/off a program that has already been selected:

- Dial **792**


Scrolling Through Available Programs

To scroll through the available programs:

- Dial **790** for the next program.
- Dial **791** for the previous program.

The numbers above for scrolling through may be programmed to a DAK. **Program off** (800) is included in the program list.

Turning On/Off Programs to Other Stations



To set up a program to another station:

- Dial **74** + station number + program number

To turn off a program at another station:

- Dial **74** + station number + 800

To set up a program to a group of subscribers:

- Dial **75** + group number + program number

To turn off a program at another group:

- Dial **75** + group number + 800

All the dialing sequences above can also be programmed on single-touch DAKs.

☞ *Access to setting up programs remotely may be restricted to certain stations.*

CONFERENCE

There are two types of conferences available, namely Simplex (Push-To-Talk) and Duplex (Handsfree).

Simplex Conference (Push-To-Talk)

There are 50 simplex conference channels available with the default numbers ranging from 8201 to 8250.

Conference off is 8200.

To connect to a conference:

- Dial the actual conference number (8201 - 8250)


You can then listen to the conversation going on in the conference. The conference numbers are programmed in the AlphaCom exchange. Single-touch keys (DAKs) may be programmed for direct access to conference groups.

To talk into the conference:

- Press **M**

The LED indicator on your station lights up to indicate that the microphone is active. Only one person can talk at a time. If you press M while someone else is talking, it has no effect (unless your station has been assigned priority to override the current talker).

While listening to a conference, you can use your station for ordinary incoming and outgoing calls. It is not possible to listen to a radio/music program while using the conference feature. You can include/exclude stations/groups remotely as you do in setting up programs.



Duplex Conference (Handsfree)


This is a handsfree conference with up to 16 participants. There are 20 duplex conference channels available, with the default numbers ranging from 8301 to 8320.

To connect to a conference:

- Dial the actual conference number (**8301 - 8320**)

To leave a conference:

- Press **C**



To include other stations while in conference:

- Dial **56** + station number


You can include/exclude stations/groups remotely by dialing the numbers **74** and **75** as you do in setting up programs.

For example, to include remote station number 2525 in conference number 8301:

- Dial **74** + 2525 + 8301

☞ *Stations participating in a duplex conference can not make or receive ordinary calls.*

DOOR OPENING



This feature requires additional door lock equipment.

Door Group Call:

Pressing the door station key sets up a Group Call to a number of stations.

- Answer by dialing **99**

You can then talk to the person who is at the door.

To open the door:

- Press **6** while in conversation with the door station.

Direct call from a door:

Pressing the door station key sets up a conversation to one station.

To Open the door from the called station:


- Press **6** while in conversation with the door station.

TELEPHONE CALLS

This feature requires additional equipment.

If you have a telephone gateway installed, you can reach telephone subscribers with both internal and external numbers from your intercom station.

Making an Internal Telephone Call




This function is available only if the telephone gateway is connected to a local PABX.

To make an internal telephone call:

1. Press **0** and wait for the dial tone.
2. Dial the internal telephone number.
3. Press **C** to end the call.

Consult the STENTOFON supervisor at your site for more information on your system setup.

Making an External Telephone Call



Depending on the system configuration you can:

Either

1. Press **0**.
2. Wait for the dial tone.
3. Dial the external telephone number.

or

1. Press **0**.
 2. Enter PIN number.
 3. Wait for the dial tone.
 4. Dial the telephone number.
- Press **C** to end the call.

☞ *Telephone numbers may be programmed to a DAK.*

Consult the STENTOFON supervisor at your site for more information on your system setup.

Calling From a Telephone To an Intercom Station

The telephone interface is set up to allow either direct calls to one specific intercom station or two-step calls to the intercom station you choose.

To call the intercom station:

1. Dial the telephone number for the telephone interface.
2. Wait for the dial tone.
3. Dial the number for the intercom station.



If your telephone has # and * keys, you can use them to activate intercom features:

- Press * to activate the **M** key (0.5 second).
- Press # to deactivate the **M** key.

To terminate the call:

- Hang up the telephone.

If two-step dialing is used, telephone callers have access to intercom features like Group Call and leaving voice messages by default. They are normally restricted from activating features like audio program selection and making outgoing telephone calls.

For more information on available features, please consult the STENTOFON supervisor at your site.

Receiving a Telephone Call at Your Station

For incoming telephone calls to your intercom station:

- Press **M** or lift the handset to accept the call.
- Press **C** or replace the handset to terminate the call.

POCKET PAGING

This feature requires additional equipment. The pagers are connected to the AlphaCom exchange/server.


☞ *If the subscriber does not have a pager, the paging attempt is ignored.*

Search:

- Call the subscriber number
- Press **9** (Search list).

For users with pagers, the pager option is usually first on the list.

Paging With Answer Option




Waiting for an answer:

1. Dial the intercom station number.
2. Dial **45** (Wait for an answer).
3. Wait for the paged person to answer from any intercom station.
The default time-out period for answering is 30 seconds.

When the paged person answers, an ordinary intercom conversation is set up with the person who initiated the paging.

If no one answers:

1. Dial the intercom station number.
2. Dial **47** (Leave a voice message).
3. Dial the message number (660-669) and any extra digits.
 - See the voice/text message number list in the User Quick Reference.
4. Press **M** if you don't want to enter the extra digits.




When the paged person answers by dialing the paging answer code from any intercom station, the voice message is played back.

The person initiating the paging gets an acknowledge message when the paging has been answered.

No conversation with the paged person is possible.

Paging Without Answer Option



To send the station number as a text message:

1. Dial the intercom station number.
2. Dial **44** (Own station number).

The pager display shows the directory number of the station activating the paging.


Answer the paging by dialing the shown directory number at the nearest intercom station.

To send a text message to the pager:

1. Dial the intercom station number.
2. Dial **46** (Text message).
3. Dial the message number (660-669) and any extra digits.
 - See the voice/text message number list in the USER QUICK REFERENCE section.
4. Press **M** when finished.

The text message and the directory number will appear in the pager display.

If the pager in question does not have a display, the attempt is canceled with a failure tone after 3 digits have been dialed.



Paging Without Calling an Intercom Station

You can activate a paging call from your intercom station to a pager directly, without calling a station first.

- Dial the pager directory number

You will then have the following options:

- Dial 44 = Send your own station no. as a text message
- Dial 45 = Wait for an answer
- Dial 46 = Send a text message
- Dial 47 = Leave a voice message

Answering Paging (Meet Me)

If you have been paged with an answer option, there are different ways of answering, depending on the pager type and the exchange programming.

At a convenient intercom station:

Either

- Dial your personal answer code.

or

- Dial the answer code shown in the pocket receiver display (default is **980 - 989**).

If your pager has no display:

- Dial **96**


Depending on the type of paging sent out, you are either connected to the person who initiated the paging, or you will hear a voice message.

DISPLAY INFORMATION

Information Display



The IP Master stations have displays with 4 lines and 20 characters each, while the Analog Master stations have displays with only 2 lines. The information displayed may be the date and time, own and called name and directory number, available functions, help text, messages, and status. The last line shows the selection button functions in the actual mode.



For the IP Master and Dual Display stations, there are 4 buttons located just below the display that correspond to the menu choices displayed. The buttons on the Dual Display station are slightly different in that there are two arrow buttons in the middle.

The text displayed will change according to your actions and the options in the actual station mode.

☞ *The information and menu text that is displayed will depend on how your intercom station is configured in the AlphaPro program.*



Interactive context help information for every function and feature is available as text messages to help guide and instruct you through each step of the procedure.

☞ *There is a separate display illumination control button for both the IP Flush Master and IP OR Master.*




Idle Station

In idle mode, the display shows the date and time, own station number and name (as set in the AlphaPro program).

In the upper-right corner of the display, there are symbols for privacy (P), handset, and volume.



Menu Selection



- Dial 60 to access the main menu info.

For IP and Dual Display stations:

- Press the [Menu] selection button to open the main functions menu.
1. Scroll up/down through the menu with the [arrow] selection buttons (the two middle buttons).




2. Confirm the desired main function by pressing [OK].
 - The secondary menu will then be shown.
3. Scroll up/down the secondary menu and confirm by pressing [OK].
 - The function will then be executed.
 - Return to the main menu by pressing [Esc].
 - Press C to return to idle mode or wait for the time-out.

For Analog stations:

The DAK 9 (lower left) key is pre-programmed as the INFO key by default.

- Press the INFO key to enter the info menu.
- Press 7 to Scroll up
- Press 9 to Scroll down
- Press 8 to Make a selection
- Press C to exit the menu or wait for time-out.

Conventional Name Search




For IP and Dual Display stations:

1. Dial **614**
 - The letters a-m is then displayed. The letters n-z will be displayed when the cursor passes the last letter (m).
2. Use the [arrow] selection buttons to scroll through the alphabet and select the first letter in the name.
3. Press the [Ok] selection button to confirm or the [Esc] selection button to cancel.
4. The first name starting with this letter is displayed.
5. Use the [arrow] selection buttons to scroll to the desired name.
6. Press the [Ok] selection button to initiate a call.



For Analog stations:

The DAK 10 (lower right) key is pre-programmed as the NAME key by default.

- Press the NAME key
- Press 7 to Scroll back
- Press 9 to Scroll forward
- Press 8 to Make a selection



Name Search in Subscriber Directory



For IP and Dual Display stations:

The [Name] selection button is used to open and search for a number in the subscriber directory.

- Press the [Name] selection button.
The display will show: AlphaNumSrch
- Confirm by pressing the [Ok] selection button.

The keyboard is now changed to alphanumeric format as used on mobile phones. Letters are not printed on the keys.

- Type in a name to search for.

The complete name or only the first characters may be typed in.

- The [up-arrow] selection button acts as a delete key (character to the left).
- The [down-arrow] selection button acts as a space bar.
- Press the [Ok] selection button to confirm when the search character(s) are typed in.

The matching name or the closest match is displayed.

- Use the [arrow] selection buttons to scroll in the directory table if needed.
- Press the [Ok] selection button to make the call or the [Esc] selection button to cancel.

The [Esc] selection button brings you back to the alphanumeric input for additional changes or input.

- Press **C** to go back to idle mode.

For Analog stations:

- Dial **9537**
- Press **M** to display the first directory entry
- Press **9** to Scroll down the alphabet
- Press **7** to Scroll up the alphabet
- Press **8** to Make a selection

Check Station Identity

To check the identity of the station:

- Dial **789**

After a few seconds, the display will automatically show the station's directory number, physical number, node number, IP address, MAC address, AMC software version, et al.

PROGRAMMING DIRECT ACCESS KEYS - DAK

The DAKs provide single-touch, immediate access to your most frequently used directory numbers and functions.

Programming DAK Directory Numbers and Functions

Different stations have different number of DAK keys.

The IP Desk Master Station has 10 DAKs while the IP OR and Flush Master Stations have 4 DAKs.

The Dual Display Master Station has 20 or more DAKs divided into pages of 10 DAKs with information text for each DAK on a 5-8 character display.

Desk and Wall Master Stations have 10 DAK keys.

To enter a directory number on a DAK:

1. Press the [Name] selection button in idle state (or dial **784** and skip to step 4).
2. Press the [arrow] selection button until you come to 9541 ProgramKey.
3. Press the [Ok] selection button.
4. You will be prompted to enter a directory or function number.
5. Press the DAK you want to program.



If the DAK is already in use, the new entry will override the old.

For a list of function numbers, see the Quick Reference Guide or select the function from the Menu and note the number displayed in front of the function name.


Deleting DAK Call Numbers and Functions

To delete a number from a DAK:

1. Press the [Name] selection button in idle state (or dial **784** and skip to step 3).
2. Press the [arrow] selection button until you come to 9541 ProgramKey.
3. Press the DAK you want to delete the number from.
4. Confirm by pressing the [Del] selection button or press the **M** key.



Direct Access Key Display Information



Dual Display Station



The Direct Access Key functions are shown on a display between the two key columns.

An arrow symbol at the top or bottom of the display indicates the previous or next page respectively. The arrow keys are used to scroll between two DAK pages in idle mode.

The text shown in the DAK display is of 3 types:

- User-defined text programmed in the DAK string.
- The first letters (5-8) of the name related to the feature or directory number assigned to the DAK.
- The directory number assigned to the DAK.

Editing DAK Text



Dual Display Station

If the predefined text on a DAK is not suitable, it may be changed by the user.

To edit DAK text:

1. Press the [Name] selection key in idle state
2. Press the [up-arrow] key until you come to 9540 EditDAKText.
3. Press the [Ok] selection key
4. Press the DAK you want to edit
 - The keyboard is now ready to accept alphanumeric entries.
 - If the DAK text was previously edited, the text is displayed.
5. Use the arrow keys to navigate
 - The up-arrow key acts as a delete key (character to the left).
 - The down-arrow key acts as a space bar.
6. Enter the new text (maximum of 8 characters).
7. Press the [Ok] selection key to confirm.

LED INDICATIONS FOR IP FLUSH MASTER



The IP Flush Master has 4 DAKs (D1 to D4) and each DAK has two corresponding LED indicators - one red and one green.

Each LED can have the following indications:

- Low priority: Steady light (no flashing)
- Medium priority: Slow flash
- High priority: Fast flash

Use the color LEDs according to the following rules:

- Green: Normal status or status that does not require immediate action
- Red: Alarm or the current mode of the station

Use flashing LEDs according to the following rules:

- Steady light: Permanent status
- Slow flash: Low priority events
- Fast flash: High priority events that require immediate action

Consequently, you can have a maximum of 6 different, independent indications on one key. Because flashing takes priority, a high priority status will mask a low priority status temporarily if they are on the same LED.

Example of LED Indicator Use

The following example shows how the LED indicators can be used for keys that are programmed at a call-in point:

- Flashing red (slow or fast): Call Request from the call-in point
- Steady red: Status activated by Remote Control Input (e.g. open door)
- Steady green: Call-in point is listening to program
- Slow flashing green: Call-in point in conversation with the master station
- Fast flashing green: Call-in point included in simplex conference

☞ *Consult the STENTOFON supervisor at your site for more information on how the LED indicators corresponding to each DAK are programmed.*

USER QUICK REFERENCE

Functions	Actions
Programming Direct Access Keys	784 + number + press DAK
Make a call	Dial subscriber number
High background noise level	Press M when you speak
End a call	C
Re-dial	9532
All Call	84 + M to speak
Group Call	85-89 + M to speak
Answer All Call / Group Call	99
Paging	Subscriber number + 44-47
Answer Paging	96 or answer code shown in display
Radio Programs	801-806 (off: C or 800)
Connect to telephone	0
Call Forwarding	71 + station number + M
Follow Me	72 + own number
Reset Call Forward / Follow Me remotely	73 + station number
Play back messages / Delete absence message	70
Wake-up / reminder within 24 hours	7883 + hour + minute + M
Wake-up / reminder after 24 hours	7883 + hour + minute + day + month
Call Request	623 + station number
Call Request transfer	7870
Conference, Simplex	8201 - 8250 (Off: 8200) M to speak
Conference, Duplex	8301 - 8320 (Off: 8300) C to leave
Ringing Group	6701 - 6710
Alphabetical Name Search	614

Number or key to press during conversation

Mute/Unmute microphone / Menu step	0	Paging with calling station number	44
Repeat absence message	1	Paging with answer	45
Inquiry Call & Broker Function	2	Text message paging	46
Call Transfer	3	Voice message paging	47
Door opening	6	Remotely change message	50
Leave voice/text message	7 + 66X	Remotely read message	51
Call Back	8	Busy Notify	57 or M
Search	9	Busy Override	58 or MM
		Private/Message Override	59 or M

Absence messages		Standard voice and text messages	
Out at the moment (until time: hhmm)	771	Contact the switchboard	660
At a meeting (until time: hhmm)	772	Call phone number xxxxxxxx	661
Gone for the day (Back tomorrow at time: hhmm)	773	Call home	663
Absent today (until date: ddmm)	774	Call your spouse	664
Busy at the moment (until time: hhmm)	775	Call me	666
At lunch (until time: hhmm)	776	Remember meeting (at time: hhmm)	667
On holiday (until date: ddmm)	777	There is a fax for you	668
Away for a few days (until date: ddmm)	778	There are deliveries for you	669
Not available (Available on phone number: xxxx)	779		

 The numbers on this page are factory default settings and may have been changed in your AlphaCom exchange installation.

www.stentofon.com

Zenitel Norway AS
P.O. Box 4498 Nydalen
NO-0403 OSLO
Norway

A100K10602

support@stentofon.com



STENTOFON products are developed and marketed by Zenitel Norway AS. The company's Quality Assurance System is certified to meet the requirements in NS-EN ISO 9001:2008. Zenitel Norway AS reserves the right to modify designs and alter specifications without prior notice, in pursuance of a policy of continuous improvement. © 2011 Zenitel Norway AS.